

**TopCore is a maintenance-friendly material for the kitchen and bathroom. Proper use and regular cleaning is necessary to keep the tabletop beautiful. With the tips below you can enjoy the worktop for years.**

## 1 DAILY MAINTENANCE

Wipe your worktop daily with a dishcloth and a clean soapy water. Always rinse thoroughly with lukewarm water and dry your worktop with a clean, dry dishcloth or kitchen paper. This will absorb any remaining dirt and any soap and water residues.

### Periodic maintenance

You can also use Top Cleaner, a special laminate cleaner that easily removes dirt from the laminate and worktop a wonderfully fresh scent. This product is available in the online shop. Always rinse well with lukewarm water and dry your worktop with a clean, dry dishcloth or kitchen paper.

## 2 SPECIFIC STAINS

### FAT, COFFEE / TEA, RED WINE

*(shiny or brown spots)*

Let the Top Cleaner or a clean soapy water of some detergent settle in for a while until the dirt starts to react. Then treat with a melamine sponge. Moisten it slightly and then squeeze it out for sufficient friction. Always rinse thoroughly with lukewarm water and dry your worktop with a clean, dry dishcloth or kitchen paper.

### LIME STAINS

*(dull white or brown spots)*

Let the cleaning vinegar settle in for a while. Then treat with a melamine sponge. Moisten it slightly and then squeeze it out for sufficient friction. Always rinse thoroughly with lukewarm water and dry your worktop with a clean, dry dishcloth or kitchen paper. Make sure that cleaning vinegar does not come into contact with marble or bluestone.

### INK, PAINT OR NICOTINE

Remove ink, paint, nicotine or felt-tip pen stains with white spirit or turpentine. Always rinse thoroughly with lukewarm water and dry your worktop with a clean, dry dishcloth or kitchen paper.

## 3 STUBBORN STAINS

Use a melamine sponge and a little soapy water. Always rinse thoroughly with lukewarm water and dry your top with a clean, dry tea towel or kitchen paper. Have the stains or rings diminished, but not yet completely disappeared? Then repeat this process. This treatment is not for the daily maintenance of your worktop!

**Note: NEVER use hard abrasives such as steel wool, sandpaper or diamonds. They can permanently damage the worktop surface!**

### IMPORTANT:

Due to the deeper structure, dirt remains in the pores. This requires more intensive cleaning than with smooth surfaces.



Never allow liquids to dry. Do not leave fats or foods on the leaf for an unnecessarily long time.



Hot pans can cause burn stains. Always use a coaster with hot objects.



Never cut directly on your worktop, always use a cutting board.



NEVER use aggressive cleaning agents such as paint remover, brush-, metal- or oven cleaners, chlorine, sink unblockers or other chemicals!



At a surface with structure more dirt remains. Thorough rinsing with clean water and rubbing dry ensures that no dirt remains in the structure of the surface.



### TOP CLEANER

Top Cleaner (item no. 290126) is a laminate cleaner for daily maintenance. Easily removes dirt from the laminate.

[www.dekkerzevenhuizen.nl/shop](http://www.dekkerzevenhuizen.nl/shop)

### More information!

Would you like more information and cleaning tips or get special offers for professional cleaners? Then check out:

[www.dekkerzevenhuizen.nl/maintenance](http://www.dekkerzevenhuizen.nl/maintenance)